



## Installation Instructions

### Dakar Bar Bracket Instructions

Part No. 50972 99-02 Chevy/GMC PU ½ Ton & LD ¾ Ton, 00-06 Chevy/GMC Tahoe/  
Suburban/Yukon, Avalanche W/body Cladding

Part No. 50976 GMC Sierra 1500/2500/3500 All

#### Parts List:

#### To attach Mounting Brackets to Vehicle:

2- Mounting Brackets Left & Right	8-3/8" Small Flat Washers	6-3/8" Lock nuts
6-3/8-16 x 1-1/4" Hex Bolts	6-3/8" Split lock Washers	2-1/2" x 1-1/4" Hex Bolts
2-1/2" x 1-1/4"OD Flat Washers	4-3/8" (Large) Flat Washers	2-1/2" Lock nuts
4-1/2" Flat washers	2-1/2" Split lock washers	

#### Installation:

- 1) Locate the Drivers and Passenger side brackets. See figure 1 for orientation. This bracket set attaches to the factory tow hook location on the frame.



- 2) Drivers, Remove tow hook bolt and nut in the frame that runs through the frame at the front of the tow hook. Remove the lower bolt behind the tow hook on the frame. Do not remove the tow hook.
- 3) Place the Drivers side bracket with the light bar mount on the outside of the frame away from the center point of the truck. Reinstall the lower bolt and longer nut and bolt removed in the previous step. Tighten all hardware. **Note:** If the vehicle does not have factory tow hooks install the bracket using 1 pc of ½ x 1-1/4" bolt, nut and washers for the lower hole and 1pc of the 3/8" x 1-1/4" bolts, nuts and washers for the side hole.
- 4) Repeat steps 2 & 3 for the passenger side.
- 5) Place the Dakar Bar into the 4 mounting holes on the brackets and install the 3/8" hardware. Tighten and adjust position.

Rampage Products 18501 Collier Ave A-101, Lake Elsinore, CA 92530

Phone: (951) 245-7400 Fax: (951) 245-5890

E-mail: [info@rampageproducts.net](mailto:info@rampageproducts.net)