

RECON

HOW TO INSTALL 26413X & 26414X

The wires for the Big Rig Ice are color coordinated differently from the wires on a Big Rig bar, please note the instructions below.

You will notice that with our new BIG RIG ICE Running Lights (part # 26413X & 26414X) there is an additional wire coming off each of the two bars. This white wire is your WHITE LED power wire and it must be connected to your dome light/cargo light. The simplest way to power this wire is to tap into the positive wire leading to either your dome light inside your cab or your cargo light which illuminates your trucks cargo bed...once connected the WHITE LEDs on your new BIG RIG ICE Running Lights will illuminate and are dominant over the amber LEDs. This means when the white LEDs are illuminated, the amber LEDs will turn off. The running light wire(yellow) and turn signal wire(red) will be connected in the same way that the standard Big Rig bar is installed. Please refer to those instructions if you need assistance with the other aspects of the install.

If you cannot locate your positive dome light wire or your positive cargo light wire, please consult with your local truck dealer to find out where these wires can be found on your particular vehicle.

GET LIT w/ RECON!!!

**If you have any questions, feel free to contact us:
info@reconaccessories.com - www.GoRecon.com**