

RECON

Removal of Ford Superduty/Excursion Outer Mirror Covers

1. Behind the larger mirrors there are 3 clips holding the cover on to the mirror.
2. There are two upper clips and one lower clip that must be unclipped for the mirror cover to release. (You will have to move the mirror side to side and up and down to gain access to the clips. The upper clips are located about 3 inches from the top of the mirror. The one lower clip is on the side closest to the truck and about 6 inches below the upper clip.)
3. Using a long flathead screwdriver, push down to remove the clips. (You may need a small flashlight to see behind the mirror itself.)
4. The mirror cover will now release from the mirror.
5. Unplug the wiring harness from the light and remove the cover and light assembly from the truck.
6. Squeeze the two butterfly clips on the inside of the light and push outwards. (Careful not to break the three guide clips on the outer side of the light.)
7. Replace the old lights with the new RECON lights in reverse order to re-install.
8. Turn the truck on and check for proper operation of both blinkers and running lights.
9. Enjoy your new RECON LED Mirror Lenses.

If you have any questions, feel free to contact us:

RECON Truck Accessories

10140 NW 53rd Street

Sunrise, Florida 33351

(877) 377-3266

info@reconaccessories.com - www.reconaccessories.com