

SpeedStack Laminated Tearoffs Installation Instructions



1. Begin with a clean visor and push all layers of one side over post button with the “Racing Optics” label facing “out” and readable as shown. “Racing Optics” is printed on the last layer (the layer to touch the shield) and must be readable from outside of the helmet!

For SmokeStack7™ and AmberStack7™ the tinted layer must touch the visor so that you pull the clear layers first.



2. Separate the tabs on the opposite side and push only the first layer (closest to the visor) over the post button as shown.



3. Fold the same tab “in” over itself, centering the large hole over the post button. While holding the tab down with finger as shown, push the next single layer over the post button. This layer will now hold the first tab folded down. Never put a crease in the fold, as it may not extend when the layer on top of it is released.



4. Continue folding each tab individually over itself and pushing the next single layer over the post button.



5. The finished side should look like this; with the outer most tab extended, ensuring one layer at a time is removed



6. With scissors, cut-off the unfolded tabs from the side you do not wish to “pull” from; or fold both sides to allow the driver to pull from their right or left. Add another SpeedStack now to double the number of tearoffs worn, or go directly to the final step.



7. Finally, tighten the post buttons with a quarter or slotted screwdriver. Turn both post buttons “out” tensioning the SpeedStack tight against the visor. Check for air gaps between the visor and the SpeedStack with a business card or piece of paper. If the post buttons do not keep the SpeedStack tight against the visor, replace both buttons or tighten the post button screws from the inside of the visor and re-tension the SpeedStack.