

--- Important ---

The WHITE WIRE that is attached to the power terminal of your switch MUST BE CONNECTED to a 12 volt power source or the LIGHTS WILL NOT WORK.

NOTE - Most states require that fog lights work only with low beams and driving lights work only with high beams. Check with local and state laws before installing.

White Wire Hook-up Options:

Driving Lights (high beam) - If you attach the white wire to your high beam circuit, your KC lights will only work when the KC switch and the high beam are on. *(If 1999 Chevy, attach to the yellow headlight wire)*

Fog Lights (Low beam) - If you attach the white wire to your low beam circuit, your KC lights will only work when the KC switch and the low beam are on. *(If 1999 Chevy, attach to the purple headlight wire)*

Fog, Driving or Off Road (ignition activated) - If you attach the white wire to an accessory circuit (air conditioner, heater, etc.), your lights will shut off automatically when you turn off the ignition. This way you will not run down your battery if you accidentally leave your KC switch on.

Fog, Driving or Off Road (battery) - If you attach the white wire to the battery, your lights will work anytime your KC switch is on, but will not be controlled by the ignition. We advise against wiring the lights this way as you can accidentally leave the lights on when turning off the ignition resulting in a low or dead battery.