

BASIC SNOWPLOWING PRACTICES

The SNOWSPORT personal utility plow was designed to make moving snow convenient and easy, and by following some simple tips, snow removal can be a safe, enjoyable experience. Always keep current with the snowfall. It's easier to plow fresh snow. Wet snow can compact and freeze which requires chipping to break it loose before attempting to move it. From the start of the season push the snow far enough out to allow for future snowfalls. Avoid overloading your equipment - push only enough snow with each pass to get the job done. To start a pass, accelerate slowly - allowing for tire traction and blade to accumulate snow. As you come to the end of a pass, lift off the accelerator and start applying brakes as needed. If snow is deep and/or compacted you may need to go over it two or three times.

- When pushing snow up to hardened snow piles – **DO SO STRAIGHT-ON – NOT AT AN ANGLE.**
- Always know the terrain before plowing
- When transporting blade, secure it to retainer brackets with snap pins
- Do not exceed 65 MPH when transporting plow
- Do not exceed 10 MPH when plowing
- Always wear your seat belt when plowing
- Never plow with your head out of the window – an unexpected sudden stop could result in personal injury
- When backing up don't rely on rear view mirrors – turn around and look where you are going
- Never pile snow on someone else's property, on street or sidewalks, by fire hydrants, mailboxes, water drains or electrical boxes
- Check with local regulations before pushing snow across roads – it may be illegal
- Do not pile snow near handicapped or parking areas
- Plow snow during low-traffic hours – be cautious of pedestrians, domestic animals and vehicles
- Never pile snow where it obstructs visibility of traffic
- Remember – always exercise safety, courtesy, and common sense
- On 4WD select low range
- On manual transmission - avoid riding clutch
- Watch engine heat gauge and avoid overheating
- Follow vehicle manufacturers specifications for snowplowing

MANUFACTURERS LIMITED WARRANTY

Agri-Cover, Inc. extends the following limited warranty on its SNOWSPORT Personal Utility Plow to the original retail purchaser:

Agri-Cover, Inc. warrants its SNOWSPORT Personal Utility Plow to be free from defects in material and workmanship under normal use for one (1) year from date of purchase.

ANY IMPLIED WARRANTY APPLICABLE TO THE SNOWSPORT PERSONAL UTILITY PLOW IS LIMITED IN DURATION TO ONE YEAR FROM THE DATE OF PURCHASE. Agri-Cover's sole obligation under this warranty or any implied warranty is limited to the repair or replacement at its option, of defective parts only. No labor or service allowance is given or implied. IN NO EVENT SHALL AGRI-COVER, INC. BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES. Some states do not allow limitations on how long an implied warranty lasts or exclusions of incidental or consequential damages, so the above limitations and exclusions may not apply to you.

To obtain part replacements under this warranty, contact the Customer Service Department of Agri-Cover, Inc. at the address shown below. Warranty registration must be on file and/or proof of original purchase (detailed and dated receipt) required for warranty to be effective.

This warranty does not cover any failure due to abuse, misuse, alteration, neglect, improper assembly or installation, or improper maintenance.

This warranty gives you specific legal rights and you may have other rights which vary from state to state.



Agri-Cover, Inc.
Customer Service Dept.
Hwy. 281 N., PO Box 508
Jamestown, ND 58402
Phone (701) 251-1427

©Copyright 2004 AGRI-COVER, INC. All rights reserved.
U.S. Patent No. 6,817,118 and other patents pending.

Part No. 30505 REV/A 120104TR1100

**ATTENTION OWNERS AND OPERATORS:
SAVE THIS INSTALLATION/OPERATORS MANUAL. READ
AND FOLLOW THE OPERATING AND SNOW PLOWING
PRACTICES.**



By: AGRI-COVER, INC.
www.mysnowsport.com